

Sea Tracker®


2 02 96 48 46 05

Quick user guide of the GPS Sea Tracker

Pair the tracker with your mobile phone by sending PH by SMS* (do only once)

2 Switch ON the tracker with the magnet, as shown in the picture (on the small cross)

Install the Sea Tracker with resin side up to the sky; no metallic parts above



Click on the Google Maps link sent by SMS at each alert

-message Fix OK means that GPS position is good

-message Fix NOK means that GPS position is not found yet,

-Battery level and external temperature are also displayed

To switch OFF the tracker, you must send Off by SMS* (the motion detector is then disabled, you must reactivate with the magnet)



When battery is below 3.6V, you must recharge it with the wireless charger

(*): the tracker will send an acknowledge by SMS

Make sure that you receive a Fix OK before immersion into water